



**BOURNEMOUTH QUICKVIEW (1704)**

Runways		
Number	ILS	Circuit (Direction/AGL)
08	(075)	Right/1200ft
26	(255)	Left/1200ft

ATSUs	
Position Ident	Frequency
EGHH_GND	121.700
EGHH_TWR	125.600
EGHH_APP	119.475
EGHH_F_APP	118.650

TA/TL		MSL	
QNH	TL	QNH	Level
1032 - 1050	FL055	<978	FL090
1014 - 1031	FL060	978-1013	FL080
996 - 1013	FL065	>1013	FL070
978 - 995	FL070		
TA = 6000ft			

Squawk Codes	
Destination	Allocation
Radar SSR	7030-7077
Aerodrome CCT	7010
UK	4301-4377
Ireland	4430 - 4477
Channel Islands	7760 - 7775
Fr/Sp/Po/SAf	2201 - 2277
Netherlands	7310 - 7677
US/CA/Carrib	7610 - 7677
Other	1140 - 1176

Stacks		
Fix	Course/Direction	Minimum Altitude
BIA	078/Left	3000ft
NEDUL	027/Right	4000ft



## Departures

From	RWY	Airway	Turn	Route
North or Northwest	08	Q41	Left turn	SAM - Q41 - NORRY - WCO SAM - Q41 - TABEN - KENET SAM - Q41 - TABEN - KENET
	26	Q41/UL9	Right turn	
Northeast East or Southeast	08	M185	Left turn	SAM - Y8 - GWC SAM - Y8 - GWC SAM - Y8 - GWC SAM - Y8 - GWC SAM - Y8 - GWC SAM - Y8 - GWC SAM - Y8 - GWC - OCK - SFD - GWC RDL 131° - BENBO - N859 - DRAKE - GWC RDL 117° - BOGNA - HARDY - SFD - Y803 - DVR - OTSID - BIG - DVR
	26	N859 Y803 L612 L151 M605 L9/L10 N16/ L9/L10	Right turn	
South	08	Q41	Right turn	THRED - Q41
	26		Left turn	
West	08	FIR	Left turn	
	26		Direct	

## Arrivals

From	Via	Route
N (FL 80 and below)	Q41	HON - WCO - PEPIS - SAM
NE	L980 L179 L610	TRIPO - TERKO - UMBUR - OCK - PEPIS - SAM TERKO - UMBUR - OCK - PEPIS - SAM NILON - UMBUR - OCK - PEPIS - SAM
NW FL 90 to FL 140 FL 150 and above (B-RNAV)	N859/ L151 L151 UL9/L9	KIDLI - DIGUT - CPT - PEPIS - SAM HON - BAMBO - EVSEM - RISIN - NUBRI - PEPIS - SAM KENET - CPT - PEPIS - SAM
S	Q41	THRED - NEDUL
SE (Paris FIR) SE (France UIR) SE (Via DVR)	N20 M8 Y8	KUNAV - ELDAX - NOTGI - GIVUN - RUDMO - MIVLA - SAM SUBIP - ELDAX - NOTGI - GIVUN - RUDMO - MIVLA - SAM DVR - LYD - WAFFU - GWC - SAM
W	—	Direct to NDB(L) BIA